

Advertising That Moves

# ski lift media

## Tube Laminating Instructions

Once the ads are built and trimmed to size they are ready to laminate

**1** Insert the ad into the laminating pouch and ensure it is centered.



**2** Insert the laminating pouch with the ad into the laminating carrier, the paper sleeve that comes with the laminating pouches, then into the laminating machine.



**3** Remove laminating pouch and allow to cool.



**4** Insert the laminating pouch in the back of the tube and centre.

**TIP:** It is best to have the ad and the words 'PAT PEND' the same direction. This will allow you to consistently line up the bottom half tube during installation.

**5** The tube is now ready for installation.





