

Advertising That Moves

ski lift media

Tube Laminating Instructions

Once the ads are built and trimmed to size they are ready to laminate

1 Insert the ad into the laminating pouch and ensure it is centered.



2 Insert the laminating pouch with the ad into the laminating carrier, the paper sleeve that comes with the laminating pouches, then into the laminating machine.



3 Remove laminating pouch and allow to cool.



4 Insert the laminating pouch in the back of the tube and centre.

TIP: It is best to have the ad and the words 'PAT PEND' the same direction. This will allow you to consistently line up the bottom half tube during installation.

5 The tube is now ready for installation.

